










# ASSEMBLY INSTRUCTION

ITEM NO: 9688GY-AC / ARMLESS CHAIR.

LEGS, HARDWARE, BACK CUSHION, PILLOW, HEADREST ARE STORED IN THE BOTTOM OF THE SEAT, PLEASE TAKE OUT FOR ASSEMBLY.

NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Seat Frame
B		1	Seat Cushion
C		1	Headrest
D	 40**17-1/2"	1	Back Cushion
E	 27-1/4**15-1/4"	1	Pillow
F	 Ø3-1/8**5-1/8"	4	Wooden Leg
G		4	Washer
H		2	Connector


## STEP 1:




# ASSEMBLY INSTRUCTION

ITEM NO: 9688GY-AC / ARMLESS CHAIR.

## STEP 2:



## STEP 3 (Completed) :



### CARE INSTRUCTION FOR FABRIC FURNITURE




In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.


°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.

# ASSEMBLY INSTRUCTION

ITEM NO: 9688GY

NO.	PARTS LIST	QTY	DESCRIPTION
A		2	9688GY-AC
B		2	9688GY-CR
C		1	9688GY-4

STEP 1 :



STEP 2 (Completed) :

