




Assembly Instruction

ITEM NO.: 8517BRW-1PW

Power Reclining Chair




Back Rest are stored at the bottom of chair, please take out it for assembly hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list


No	Drawing	Qty	Description
A	A line drawing of a chair seat, showing the front, backrest, and side panels. It has a small circular hole on the front panel.	1	SEAT
B	A line drawing of a rectangular backrest panel with a curved top edge and a small tab on the right side.	1	BACK REST
C	A line drawing of a power plug with a rectangular head and a cord attached to the bottom.	1	PLUG
D	A line drawing of a rectangular adaptor block with a cord attached to the bottom left corner.	1	ADAPTOR

Step #1



Step #2





Care Instruction for Polished Microfiber Furniture:

In order to maintain the original appearance of your Polished Microfiber Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Polished Microfiber .
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.